
DREO | **Smart Tower Fan**
Cruiser Pro T2S

USER MANUAL



www.dreo.com

Looking for help?

Contact us to get expert support.

support@dreo.com **(888) 290-1688** **www.dreo.com**

Mon - Fri, 9:00 am-5:00 pm PST/PDT

"

Thanks for Choosing DREO!

Your support means the world to us. We hope you enjoy our product as much as we did creating it.

CONTENTS

1 IMPORTANT SAFETY INSTRUCTIONS 1-2

2 ASSEMBLING YOUR TOWER FAN 3-5

3 CONNECTING TO YOUR TOWER FAN CRUISER PRO T2S 6

4 KNOWING YOUR TOWER TOWER FAN 7-8

5 USING YOUR TOWER FAN 9-13

6 CLEANING AND MAINTENANCE 14-15

7 TROUBLESHOOTING 16

8 TROUBLESHOOTING 17-18

IMPORTANT SAFETY INSTRUCTIONS

READ ALL CAUTIONARY MARKINGS ON THE APPLIANCE AND SAFETY INSTRUCTIONS IN THE USER MANUAL BEFORE USE.



Do not cover the air inlet and outlet while in operation.



Do not use the fan near flammables and combustibles.

General Safety

1. Children shall not play with the appliance. Cleaning and maintenance shall not be performed by children without supervision.
2. Use the appliance as described in the user manual only. Any other use not recommended in the user manual may cause fire, electrical shock, or personal injury.
3. This appliance can be used by children aged above 8 years and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of this appliance in a safe way and understand the hazards involved.

Operation Safety

1. Place the appliance on a flat, dry surface before use.
2. **Do not** immerse in water and any other liquids.
3. **Do not** use the appliance until the base is installed.
4. **Do not** insert your fingers,pencil and any other objects into the grilles while im operation.
5. **Do not** dismantle, repair, or modify. All servicing should be performed by qualified personnel.

Electricity Safety

1. Make sure that the voltage of your electricity supply is the same as that indicated on the appliance.
2. Always unplug before cleaning or leaving the appliance unused for a long period of time. Keep your hands dry when plugging / unplugging.
3. Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
4. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliance.Arrange cord away from traffic area and where it will not be tripped over.
5. **WARNING:** To reduce the risk of fire or electric shock, do not use this Fan with any solid-state speed control device.
6. This appliance employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions and check the appliance. If the replacement fuse blows, a short-circuit may be present and the appliance should be discarded or returned to an authorized service facility for examination and/or repair.
7. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way, If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

FOR HOUSEHOLD USE ONLY READ AND SAVE THESE INSTRUCTIONS

Gentle Reminder:

Check the appliance regularly and refer to TROUBLESHOOTING or contact our customer support if it shows any of the following signs:

- Power cord or plug is damaged.
- Loud noise, unusual smell or excessive heat.

Specifications


Model No.	DR-HTF002S
Input	AC 120V 60Hz
Rated Power	50W
Battery Type	CR2025 3V

ASSEMBLING YOUR TOWER FAN

Assembly Instructions


When using the appliance for the first time, remove the wraps and attach the parts by following the steps below.

1




Keep the base halves in a crossed position, then hook the arched cutout on one half onto the arched support on the other half.

2




Press down on edges to click two base halves together.

3




Run the cord through the center hole.

4




Fit the base onto the bottom of the fan by aligning the arrows on the underside.

5




Rotate the base clockwise to lock in place.

6




Thread the cord through all REAR cord keepers and put the fan upright.



CAUTION

- Do not operate the tower fan if the base has not been installed.
- Make sure to thread the cord through all rear cord keepers.

Package Contents



CONNECTING TO YOUR TOWER FAN CRUISER PRO T2S

3

Before connecting the appliance to your mobile device, please scan the QR code on the left or go to the app store and search **"Dreo"**, then select and download the app.

Download on the App Store

GET IT ON Google Play

Look for "Cruiser Pro T2S" when connecting your new tower fan.

You can use the Dreo app to connect your smart tower fan to **Amazon Alexa** or **Google Assistant**. Please follow the in-app instructions to set up your voice assistant.


NOTE: You must create a Dreo account to access voice assistants.

1. Launch Dreo and sign in or create account by following in-app instructions.
2. Enable Bluetooth on your mobile device and plug in your tower fan.
3. Tap **+ Add Device** and select **Cruiser Pro T2S**.
4. Hold the Oscillation button for 5 seconds to start WiFi connection settings.
   (Tip: The WiFi icon will keep flashing when pairing.)
5. Follow in-app instructions to complete WiFi connection.
6. You're now ready to control the appliance on your app.
   (Tip: To restart connection settings, hold the Oscillation button again for 5 seconds.)

KNOWING YOUR TOWER FAN

4

Control Panel



Power Button
- Turn power on/off
- Long press 10s to reset to factory settings

Mode Button
- Switch between Normal/Natural/Sleep/Auto Mode
- Long press to display temperature or fan speed


Fan Speed Button
Adjust airflow volume (1-6 levels)

Mute Button
Turn on/off button sounds

Timer Button
Select to set a timer (0-12h)

Oscillation Button
- Adjust airflow direction
- Long press 5s to start network settings and device pairing


LED Display



USING YOUR TOWER FAN

5

General Operations



1. Touch ⏻ to turn on, and ☰ to choose a working mode.
2. Touch ✿ to adjust the airflow volume.
3. Touch ◡ to change the airflow direction.
4. Touch 🕒 to set a timer.
5. Touch ⏻ to turn off the tower fan.

Working Modes

Sleep Mode (Mute Auto On)

Fan speed decreases every 30 minutes.

Speed decreases by two levels at most and will remain constant if at level 1:

For level 6: 6→5→4
For level 5: 5→4→3
For level 4: 4→3→2
For level 3: 3→2→1
For level 2: 2→1
For level 1: 1

Auto Mode
Fan speed adapts to the ambient temperature.

Normal Mode
Fan runs at the constant speed.

Natural Mode
Fan runs at alternating speeds.

Other Features

Mute
Touch the mute button on the remote control to turn on/off button sounds.

Speed/Temp Switch (long press)
The LED display shows the fan speed by default. Long press the Mode button ☰ to switch to temperature.

Firmware Update
Check the firmware version on the Dreo app and update regularly for the fan to work more efficiently.

Display will show "UP" during the update process. Do not operate until the update is completed.

Timer
When the fan is ON, Touch the timer button repeatedly to set a timer (1-12 h). When the timer ends, the fan will stop running automatically. To cancel, set the time to 0 hour.

Note: *Display will return to fan speed after 10 seconds.*

Memory
If the fan is turned OFF and connected to power, it will operate under the previous settings (except the timer setting) when it is turned ON again.

Display Auto Off
- Display turns off after 1 minute (after 5 seconds in sleep mode).
- Wake up the display with any button.
- To disable this feature, please go to the Dreo app.


Getting the Most out of Your Tower Fan

1. Remove any tall obstacles that might block the airflow from the fan.


2. Combine with your AC unit to get cooler air throughout the room.

3. Position the tower fan closer to you to get more direct airflow.


4. Place a bucket of ice in front of the fan for an extra cooling boost.



Remote Control



Battery Replacement



1. Press the locking button to pop out the battery holder.
2. Replace with the same battery type with the (+) side facing up.
3. Push in the holder until securely locked into place.

Note: *If the indicator on the remote control doesn't turn on any more, please consider replacing the battery.*

WARNING


- **INGESTION HAZARD:** This product contains a button cell or coin battery
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause Internal Chemical **Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
b) Even used batteries may cause severe injury or death.
c) Call a local poison control center for treatment information.
d) Compatible battery type: CR2025.
e) Battery nominal voltage:3.0 Vdc
f) Non-rechargeable batteries are not to be recharged.
g) Do not force discharge, recharge, disassemble, heat above (rated temperature: 140 °F) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
h) Ensure the batteries are installed correctly according to polarity (+ and -).
i) Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
j) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
k) Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

CLEANING AND MAINTENANCE

6



Outer Surface

Gently wipe off the dust with a soft, dry cloth.

Grilles & Blades

Remove the dust using a vacuum or air duster.

Base


The base can be disassembled in reverse order of assembly.

CAUTION

1. Always unplug the fan before any cleaning or maintenance to avoid the risk of fire, electric shock, or injury to persons.
2. Do not immerse in water or get water inside the motor housing.
3. Do not use any chemical agents when cleaning the fan.
4. Store in a cool, dry place and cover it to protect from dust.

User Servicing Instructions (Fuse)

This appliance features a fused safety plug that protects against overload or short-circuit situations. If the fuse blows, please cut off power and follow the below instructions or consult a qualified electrician.



1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.
3. Remove fuse carefully. Push the fuse from the other side to remove the fuse.
4. Risk of fire. Replace fuse only with 2.5 Amp, 125 Volt fuse.
5. Close fuse cover. Slide closed the fuse access cover on top of attachment plug.

WARNING

Risk of fire. Do not replace attachment plug. Contains a safety device(fuse) that should not be removed. Discard product if the attachment plug is damaged.

TROUBLESHOOTING 7

My fan won't turn on!

1. Make sure that the cord is connected to a powered outlet and the mains voltage corresponds with the voltage indicated on the fan.
2. Check if the fuse has blown. If the fuse has blown, please refer to **page 15**.

My fan is shaky and wobbling!

1. Place the fan on a flat, level surface.
2. Incorrect installation might also cause shakiness. Please refer to the assembly instructions in **page 3-4**. Note that the power cord must be run through all three keepers.

My fan is making vibration and noise!

1. Place the fan on a flat, level surface.
2. Be sure not to insert anything into the air inlet and outlet.

If your problem is not listed or still persists, please feel free to contact us. This appliance is covered with 12-month warranty by default. Extend your warranty for free by registering your product at dreo.com/warranty

FCC STATEMENT

This device complies with Part 15 of the FCC Rules.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Model No.: DR-HTF002S
Rev_1.4_EN

We're Here to Help!

(888) 290-1688 Mon - Fri, 9:00 am-5:00 pm PST/PDT
support@dreo.com
www.dreo.com
Shenzhen Hesung Innovation Technology Co., LTD
26F, Bldg A7, Creative City, Shenzhen, China

MADE IN CHINA

Intertek 5020677