
Cool & Warm Mist Humidifier

USER MANUAL



25.02.12_1.0

”

Thanks for Choosing DREO!

Your support means the world to us.
We hope you enjoy our product as much as we did creating it.

CONTENTS

01

KNOWING YOUR HUMIDIFIER

1-4

02

USING YOUR HUMIDIFIER

5-7

03

CLEANING AND MAINTENANCE

8-14

04


TROUBLESHOOTING

15-16


KNOWING YOUR HUMIDIFIER

01


Package Contents



Bottom



Base





User Manual

Quick Start Guide

Quick Start Guide



Absorption Pad



Cleaning Brush



Aroma Pad

Control Panel



Power Button
- Turn the humidifier on/off.
- Long press for 7 seconds to restore WiFi and factory settings.



Manual Mode Button
Switch between Low/Medium/High mist level



Auto Mode Button
- Touch the Auto Mode button to increase the target humidity by 5%. (Target humidity ranges from 30% to 90%.)
- In Auto Mode, mist level is adjusted according to your target humidity.



Warm Mist Button
Turn warm mist off/on
Note: The warm mist is turned on by default.




Humidity Indicator Light
Turn the humidity indicator light on/off.



Timer /WiFi Settings
- Select to set a timer (0-12H)
- Long press for 5 seconds to enter WiFi settings.

LED Display



Note:

- When humidity levels are below 10%, the display will show "LO".
- When humidity levels are above 90%, the display will show "HI".
- When the water is low, the Low Water Level Indicator will flash for 5 seconds then the humidifier will switch to standby.
- The Sleep Mode, Schedule, and Cartridge Change Reminder are only available via the DREO app.

Humidity Indicator Light



The indicator light will change according to your room humidity level.

Light Color	Humidity Level
Yellow	≤30%
Green	31% - 60%
Blue	≥61%


USING YOUR HUMIDIFIER

02

Before Use


When using your humidifier for the first time, remove the wraps and follow the steps below.

❶




Make sure the cartridge is installed correctly and the label and the cardboard have been removed.

❷



Detach the cover and water tank from the humidifier and clean thoroughly.


❸



Fill the tank with water, making sure the water doesn't pass the MAX line.


Note: DO NOT add water into the mist tube.

❹



Put the water tank back in place and close the top cover.

❺




Place the humidifier on a flat, level surface, and rotate the nozzle to adjust the mist direction away from walls or any major obstacles.

ATTENTION:

- It is recommended to add purified or distilled water to prevent white powder residue from forming.
- Do not add essential oil into the water tank to avoid damage to the tank.
- Do not place the humidifier on the carpet or floor directly.
- Direct the mist away from walls, furniture and electrical appliances.
- It is recommended to place a water-resistant mat under the humidifier to catch spills and droplets.
- It is recommended that the humidifier be placed away from air purifiers or smoke alarms.


Adding Essential Oil

❶




Push to open the aroma tray.

❷



Add 5-10 drops of essential oil on the aroma pad.


❸



Put the aroma pad tray back in place.

Note:
- Add essential oils on the aroma pad only. Do not add into the water tank or any other places.
- The scent may be soft, this humidifier is not intended to work as an aroma diffuser.
- The scent level cannot be adjusted.
- If the aroma pad becomes too stiff, it needs to be replaced.

Absorption Pads



The mineral absorption pads help reduce mineral buildup (scale) inside the humidifier, especially on the heating element.

Note:The absorption can be reused after cleaning, but it is recommended replace it regularly.


CLEANING AND MAINTENANCE

03

- Always turn off and UNPLUG the humidifier before any cleaning or maintenance.
- Do not clean the main body under running water.
- Do not let water splash into the air outlets.
- Do not use any chemical agents when cleaning the humidifier.
- Store in a cool, dry place and cover it to protect from dust.
- Do not overfilling the humidifier due to the potential risk of electric shock.


Cleaning

❶




Detach the water tank from the base.

❷



Remove the hot/cold mist mixer.

❸




Take out the water tank cover, drain any remaining water from the tank and the base.
Note: If you've used the warm mist setting, use with caution in case the water is still hot.

❹




Rinse the tank with lukewarm water.

❺




Gently clean the base with a soft cloth or the included cleaning brush.

❻




Put the hot/cold mist mixer back in place.

❼




Wipe the tank clean with a soft, damp cloth.

❽



Fill the tank with room temperature water. Do not fill with hot water.

❾




Attach the water tank to the base, replace the top cover.

Descaling

RECOMMENDED ONCE A MONTH


❶



Detach the water tank from the base. Take out the water tank cover and rinse it with warm water.


For a thorough cleaning, you may detach the nozzle from the cover and clean it with the included brush.

❷



Drain any remaining water from the tank and the base.


❸



Fill the tank with a solution of citric acid and water (one teaspoon of citric acid for each gallon of water). Replace the tank cover and shake around the tank.


❹

15-20min




Attach the water tank to the base. Let it sit for 15-20 minutes.

❺




Remove the tank and detach the cover, drain any remaining solution from the tank and the base. Rinse the tank with water.

❻



Remove the nozzle, droplet collector, cartridge, hot/cold mist mixer, noise silencer, and float.

❼




Clean all parts with a soft cloth, you may use the included cleaning brush to remove excess of mineral deposit. Make sure all parts are dry before reassembling your humidifier.

Cleaning the aroma pad tray


RECOMMENDED ONCE A WEEK

❶



Pull out the aroma pad tray at the back of the base.


❷



Rinse with water and place back into the base.


Reassembling

❶




Place the cartridge back into the tank. Make sure the cartridge clicks in place.

❷




Fix the left prong on the bracket, then slide the other prong to secure the float in place.

❸




Place the absorption pad and the noise silencer back to the PTC heater.

❹




Place the hot/cold mist mixer back to the base.

❺




Place the aroma pad back into the aroma box.


Is Your New Humidifier Leaking?




Make sure to remove the label and the cardboard.



Fix the left prong on the bracket, then slide the other prong to secure the float in place.




Remove any particles or hair blocking the water valve.




Make sure the humidifier is placed on a flat surface.

Contact Customer Service If...



The water valve is not flat or the tank leaks water when refilling.



Your water tank has leakage due to prolonged use of essential oils.

If your humidifier keeps leaking water, please contact customer support.

TROUBLESHOOTING 04

My humidifier does not work.

1. Make sure that the cord is connected to a powered outlet and the mains voltage corresponds with the voltage indicated on the humidifier.
2. The humidifier will shut down automatically in the event of low water.
3. Check the water tank is installed properly.

My humidifier is not misting.

1. Please check whether the air inlet is blocked.
2. The water in water reservoir is nearly used up.
3. Your room might have too much ventilation. Please close doors and windows.

The mist produces an unpleasant smell.

1. Use purified or distilled water only. It is not recommended to use tap water.
2. Change water regularly to avoid dirty water accumulation.
3. Clean the humidifier and keep it dry for 12 hours with the cover detached.
4. Clean the aroma pad tray, change the aroma pad.

Water leaks from my humidifier.

1. Make sure the silicone sealing ring around the water outlet valve is secure.
2. Avoid running the humidifier in a room with over 60% relative humidity.
3. Wipe any excess water.
4. Do not shake the humidifier.
5. Make sure to place the humidifier on a flat, level surface.
6. Check the water tank for leaks. If there are leaks, contact Customer Support.

Humidifier uses water too quickly.

1. The humidifier uses up water based on the environmental temperature and humidity. If your environment is cold and/or dry, the humidifier will run out of water faster.
2. Using the warm mist function will use up water faster.
3. Switch to Auto Mode to adjust mist level based on your room's humidity.

White dust appears around the humidifier.

1. It is recommended to purchase the DREO replacement filter that filters out white dust.
2. Using purified or distilled water to fill the humidifier. Avoid using water with high mineral content, such as tap water.
3. Clean the humidifier regularly (see Cleaning & Maintenance, page 8).

Mist is not warm enough after pressing .

1. Press to adjust the mist temperature from 113°F to 133°F.
2. Allow the humidifier to heat up for about 5-10 minutes to produce warm mist.
3. Clean and descale the heating element (see Cleaning & Maintenance, page 8).

Humidity in the room remains unchanged.

1. Use a higher mist level setting.
2. Depending on your environment, the humidifier may take longer to humidify your air.
3. The room may be larger than the humidifier's effective range. If the room is larger than 215–430 ft^2 / 20–40 m^2, the humidifier will not be as effective.

DREO

www.dreo.com

Looking for help?

Contact us to get expert support.

(888) 290-1688 (Only for N.A.)
Mon - Fri, 9:00 am-5:00 pm PST/PDT

support@dreo.com (N.A.)
uk-support@dreo.com (U.K.)
eu-support@dreo.com (E.U.)

www.dreo.com